

(12) INTERNATIONAL APPLICATION PUBLISHED UNDER THE PATENT COOPERATION TREATY (PCT)

(19) World Intellectual Property Organization  
International Bureau



(43) International Publication Date  
26 June 2003 (26.06.2003)

PCT

(10) International Publication Number  
**WO 03/051867 A1**

(51) International Patent Classification<sup>7</sup>: **C07D 401/12**,  
C07B 57/00 // C07M 7/00

SG, SK, SL, TJ, TM, TN, TR, TT, TZ, UA, UG, US, UZ,  
VC, VN, YU, ZA, ZM, ZW.

(21) International Application Number: PCT/SE02/02356

(22) International Filing Date:

17 December 2002 (17.12.2002)

(25) Filing Language:

English

(26) Publication Language:

English

(30) Priority Data:

0104295-1 18 December 2001 (18.12.2001) SE

(71) Applicant (for all designated States except US): **ASTRAZENECA AB** [SE/SE]; S-151 85 Södertälje (SE).

(72) Inventors; and

(75) Inventors/Applicants (for US only): **ANDERSSON, Shalini** [SE/SE]; Astrazeneca R & D Mölndal, S-431 83 Mölndal (SE). **JUZA, Markus** [DE/CH]; Carbogen Laboratorios AG, Schachcnallee 29, CH-5001 Aarau (CH).

(74) Agent: **GLOBAL INTELLECTUAL PROPERTY**; Astrazeneca AB, S-151 85 Södertälje (SE).

(81) Designated States (national): AE, AG, AL, AM, AT, AU, AZ, BA, BB, BG, BR, BY, BZ, CA, CH, CN, CO, CR, CU, CZ, DE, DK, DM, DZ, EC, EE, ES, FI, GB, GD, GE, GH, GM, HR, HU, ID, IL, IN, IS, JP, KE, KG, KP, KR, KZ, LC, LK, LR, LS, LT, LU, LV, MA, MD, MG, MK, MN, MW, MX, MZ, NO, NZ, OM, PH, PL, PT, RO, RU, SC, SD, SE,

(84) Designated States (regional): ARIPO patent (GH, GM, KE, LS, MW, MZ, SD, SL, SZ, TZ, UG, ZM, ZW), Eurasian patent (AM, AZ, BY, KG, KZ, MD, RU, TJ, TM), European patent (AT, BE, BG, CH, CY, CZ, DE, DK, EE, ES, FI, FR, GB, GR, IE, IT, LU, MC, NL, PT, SE, SI, SK, TR), OAPI patent (BF, BJ, CF, CG, CI, CM, GA, GN, GQ, GW, ML, MR, NE, SN, TD, TG).

**Declarations under Rule 4.17:**

— as to applicant's entitlement to apply for and be granted a patent (Rule 4.17(ii)) for the following designations AE, AG, AL, AM, AT, AU, AZ, BA, BB, BG, BR, BY, BZ, CA, CH, CN, CO, CR, CU, CZ, DE, DK, DM, DZ, EC, EE, ES, FI, GB, GD, GE, GH, GM, HR, HU, ID, IL, IN, IS, JP, KE, KG, KP, KR, KZ, LC, LK, LR, LS, LT, LU, LV, MA, MD, MG, MK, MN, MW, MX, MZ, NO, NZ, OM, PH, PL, PT, RO, RU, SC, SD, SE, SG, SK, SL, TJ, TM, TN, TR, TT, TZ, UA, UG, UZ, VC, VN, YU, ZA, ZM, ZW, ARIPO patent (GH, GM, KE, LS, MW, MZ, SD, SL, SZ, TZ, UG, ZM, ZW), Eurasian patent (AM, AZ, BY, KG, KZ, MD, RU, TJ, TM), European patent (AT, BE, BG, CH, CY, CZ, DE, DK, EE, ES, FI, FR, GB, GR, IE, IT, LU, MC, NL, PT, SE, SI, SK, TR), OAPI patent (BF, BJ, CF, CG, CI, CM, GA, GN, GQ, GW, ML, MR, NE, SN, TD, TG)

— of inventorship (Rule 4.17(iv)) for US only

**Published:**

— with international search report

For two-letter codes and other abbreviations, refer to the "Guidance Notes on Codes and Abbreviations" appearing at the beginning of each regular issue of the PCT Gazette.

(54) Title: **NEW PROCESS**

(57) Abstract: The present invention relates to a process for the preparation of certain 2-pyridinyl)methyl)sulfinyl]-1H-benzimidazoles compounds. More specifically it relates to the preparation of an enantiomerically pure or optically enriched enantiomer of either omeprazole, pantoprazole, lansoprazole, or rabeprazole from a mixture containing the same using means for simulated moving bed chromatography.

WO 03/051867 A1

## NEW PROCESS

### *Field of the invention*

The present invention relates to a process for the preparation of certain 2-(pyridinyl)methylsulfinyl]-1H-benzimidazoles compounds. More specifically it relates to the preparation of an enantiomerically pure or optically enriched enantiomer of either omeprazole, pantoprazole, lansoprazole, or rabeprazole from a mixture of the enantiomers using means for simulated moving bed chromatography.

### *Background of the invention and prior art*

The compound 5-methoxy-2-[[[(4-methoxy-3,5-dimethyl-2-pyridinyl)methyl]sulfinyl]-1H-benzimidazole, having the generic name omeprazole, as well as pharmaceutically acceptable salts thereof, are described in EP 5129. Omeprazole is the first member in a family called proton pump inhibitors. Proton pump inhibitors are effective in inhibiting gastric acid secretion, and are consequently useful as antiulcer agents and have revolutionized the treatment of gastrointestinal disorders. Other proton pump inhibitors, such as pantoprazole, lansoprazole, and rabeprazole, are all substituted pyridylsulfinyl benzimidazoles and therefore structurally closely related to omeprazole.

Omeprazole is a sulfoxide and a chiral compound, with the sulfur atom being the stereogenic center. Thus, omeprazole is a racemic mixture of its two single enantiomers, the *R*- and *S*-enantiomer of omeprazole.

Pantoprazole, lansoprazole, and rabeprazole, as well as pharmaceutically acceptable salts thereof, are described in US 4,758,579; US 4,628,098; and US 5,045,552, respectively. Traditional chemical synthesis of chiral compounds usually gives the racemic mixture.

In the field of pharmaceutical industry it is an extremely important task to prepare optically pure compounds in order to improve the efficacy of pharmaceuticals per unit dose and to avoid side effects. *S*-omeprazole for example, has less inter-patient variability of response to treatment than the racemate as well as the corresponding *R*-isomer.

The separation of a mixture of optical isomers, *i.e.* optical resolution, has traditionally been performed according to the diastereomer method, the crystallization method, or the enzyme method. In all these methods however, the types of compounds for which optical resolution is feasible are often limited. Resolution of omeprazole using a chiral acyl group, such as mandeloyl, is described in WO 94/27988. Resolution of omeprazole using a crystallization method is described in WO 97/02261. Resolution of omeprazole by bioreduction is described in WO 96/17077 and an enantioselective preparation of omeprazole by biooxidation is described in WO 96/17076.

Chromatography has been recognized as a valuable analytical method, but the potential of preparative chromatography in separating racemates into their optical antipodes to compete with stereoselective synthesis or traditional resolution has been overseen. In addition, a large quantity of an eluent is needed too and the concentration of the desired compound in an eluate is extremely low, so that much energy and complicated process are required for recovery. Therefore, the development of a method capable of efficient separation in a large quantity has been desired in the art.

Separation of the enantiomers of omeprazole using chromatography is *i.a.* described in *Analyt. Biochem.*, 136, 293-297 (1984), Allenmark et al.; *J. Chromatogr.*, 456, 323-336 (1988), Marle et al.; *J. Chromatogr.*, 532, 305-319 (1990), Erlandsson et al.; *J. Chromatogr.*, 553, 373-381 (1991), Lindner et al.; *J. Chromatogr.*, 586, 233-248 (1991), Marle et al. Further WO 92/08716 relates to a process for the resolution of certain chiral pyridylmethylsulphonyl-1H-benzimidazoles into their enantiomers.

The concept of simulated moving bed (SMB) was described in the late 1950's, see *e.g.* U.S. Patents 2,957,927; 2,985,589; 3,205,166; 3,291,726 and 3,310,486. Not all stationary phases designed for analytical purposes are equally suited for preparative chromatographic separation of large amounts of a racemate, mainly due to practical and / or economical reasons (availability, cost, mechanical and chemical stability, loadability, etc etc). The chiral stationary phase has to be available in large amounts, with reproducible batch-to-batch properties and at a relatively low cost relative to the value of the enantiomers to be separated.

*Description of the invention*

The present invention relates to a process for chromatographically resolving enantiomerically pure or optically enriched omeprazole, pantoprazole, lansoprazole, or rabeprazole using means for a simulated moving bed (SMB) system:

Counter-current flows are used efficiently in different chemical processes, such as heat exchanger, extraction, etc. The idea is to implement counter-current adsorption processes involving flows of both the fluid and solid phases in opposite directions. In a true moving bed (TMB) an actual circulation of solid occurs while in an SMB system the solid movement is simulated. A schematic SMB unit is shown in Figure 1 below and is thus constituted of a number of chromatographic columns, separated by ports where inlet and outlet streams can be fed or collected. The countercurrent solid movement is simulated by periodically shifting the feed and withdrawal points of the unit in the same direction as the mobile phase flow. Four external streams are present, the feed mixture, the desorbent, *i.e.* the eluent or the mixture of eluents constituting the mobile phase, the extract stream enriched in the enantiomer A, and the raffinated stream enriched in the enantiomer B.




Figure 1. SMB system in a 2-2-2-2 configuration; B is less retained enantiomer and A is more retained enantiomer

These streams divide the unit in four sections, section I between the desorbent inlet and the extract port, section II between the latter and the feed inlet, section III between this and the raffinate outlet and section IV between the raffinated port and the desorbent inlet. Each of these sections plays a specific role in the process. The separation is performed in sections II and III, where the less retained enantiomer B must be desorbed and carried by the mobile phase towards the raffinate, while A is retained by the stationary phase and carried towards the extract port through the simulated solid movement. In section I the stationary phase is regenerated by the fresh mobile phase stream and A is conveyed towards the extract port. Finally, in section IV the mobile phase is regenerated by adsorbing the amount of enantiomer B not collected in the raffinate. In this way both the stationary phase and the mobile phase can be recycled to section IV and I, respectively.

The simulated moving bed chromatography for the production of enantimerically pure or optically enriched omeprazole from a mixture comprising the two enantiomers is thus achieved using a set of columns packed with a chromatographic chiral stationary phase (CSP) capable of chiral recognition, ports for the continuous introduction of solvent desorbent (mobile phase) and feed, ports for continuous removal of raffinate (solution containing the less strongly retained enantiomer B), and extract (solution containing the more strongly retained enantiomer A) and a means of recycling fluid through the system. The columns are connected such that the outlet of each column is connected to the inlet of the next column also the outlet of the last column being connected to the inlet of the first column.

The present invention is thus characterized by introducing a solution containing a mixture of the two enantiomers of omeprazole and a desorbing liquid into a plurality of columns containing a CSP therein and having front and rear ends thereof connected to each other endlessly via a fluid passage to circulate a fluid unidirectionally and at the same time drawing out a solution containing one of the separated isomers and another solution containing the other isomer from the columns, wherein a port for introducing a desorbing liquid, a port for drawing out a solution containing a strongly adsorbable optical isomer, *i.e.* an extract, a port for introducing a solution containing a mixture of optical isomers, and

a port for drawing out a solution containing a weakly adsorbable optical isomer, *i.e.* a raffinate, are arranged on the columns in this order along the direction of fluid and the positions of these ports are successively moved in the direction of fluid flow in the columns intermittently.

The basic operations of an SMB process are adsorption, concentration, desorption, and desorbing liquid recovery and these elements are continuously carried out in the process of the present invention.

#### *Adsorption*

The mixture of the two enantiomers of omeprazole is brought into contact with the CSP, so that a strongly adsorbable enantiomer (strongly adsorbable component A) is adsorbed while another weakly adsorbable enantiomer (weakly adsorbable component B) is recovered as a raffinate flow together with the desorbing liquid.

#### *Concentration*

The column having the strongly adsorbable component adsorbed thereon is brought into contact with part of the extract described below, so that the weakly adsorbable component remaining on the column is expelled and the strongly adsorbable component is concentrated.

#### *Desorption*

The column containing the concentrated strongly adsorbable component is brought into contact with the desorbing liquid, so that the strongly adsorbable component is expelled from the column and recovered together with the desorbing liquid as an extract flow.

#### *Desorbing Liquid Recovery*

The column having substantially only the desorbing liquid adsorbed thereon is brought into contact with part of the raffinate flow, so that part of the desorbing liquid contained in the column is recovered as a desorbing liquid recovery.

The flow can be the same or different in the four basic operations indicated above, of which the latter is preferred.

As is indicated in Figure 1 an SMB system consists of 4 zones. Each zone is defined relative to an injection point and a collection point.

Zone I – between the eluent and extract lines.

Zone II – between the extract and feed lines.

Zone III – between the feed and raffinate lines.

Zone IV – between the raffinate and eluent lines.

The liquid flowing out of zone IV is recycled to zone I. As an example in the case of a binary mixture A+B, A being the less retained component it is possible to choose operating conditions, i.e. flow rates in zones I, II, III, and IV, in order to make A move in one direction, e.g. upwards, and B move in the other direction, e.g. downwards. A and B can thus be recovered respectively in the raffinate and extract streams as pure compounds.

In fact it is extremely difficult to operate a TMB because it involves circulation of a solid adsorbent. This is the reason why another implementation is suitable – the simulated moving bed (SMB). Most of the benefit of counter-current operation can be achieved by using several fixed-bed columns connected in series and an appropriate shift of the injection and collection points. To simulate a counter-current flow, the feed, eluent, extract and raffinate lines are all moved one column (or more) forward in the fluid flow direction at fixed time intervals.

For purposes of this invention, various terms used herein are defined as follows.

A “feed mixture” is a mixture containing one or more extract components and one or more raffinate components to be separated by the process, e.g. the enantiomers of omeprazole.

The term “feed stream” indicates a stream of a feed mixture that passes into the adsorbent, i.e. the CSP, used in the process.

An "extract component" is a compound or class of compounds that is more selectively adsorbed by the adsorbent while a "raffinate component" is a compound or type of compound that is less selectively adsorbed.

The term "desorbent material" shall mean generally a material capable of desorbing an extract component from the adsorbent.

The term "raffinate stream" or "raffinate output stream" means a stream in which a raffinate component is removed from the apparatus.

The term "extract stream" or "extract output stream" shall mean a stream in which an extract material that has been desorbed by a desorbent material is removed from the apparatus.

The term "compound(s) of the present invention" shall mean enantiomerically pure omeprazole, pantoprazole, lansoprazole, or rabeprazole.

Typically at least a portion of the extract stream and the raffinate stream are passed to separation means, normally evaporators or crystallizers but possibly a fractional distillation column, wherein at least a portion of desorbent material is recovered. This will also produce an extract product and possibly a raffinate product.

Continuous SMB systems have numerous advantages over batch-type processes. An SMB process produces a constant uniform composition product. It is flexible and the recovery and purity of the product can normally be adjusted. An SMB process apparatus comprises many serially- connected columns with intermediate points for the appropriate addition or removal of feed, extract, desorbent and raffinate streams. Cyclic advancement of the input and output streams through the apparatus can be accomplished by a multiple valve manifold system. In these simulated moving bed systems the adsorbent is usually divided between eight or more columns. The configuration of the eight columns may not necessarily be 2+2+2+2, as is schematically shown in Figure 1. A column configuration of 5+1+3+3, or any other distribution of columns including those with variable-lengths chromatographic zones, is also feasible. Equipment utilizing these SMB principles can vary in size. The most difficult part is finding an effective adsorbent/desorbent system and suitable conditions.



In simulated moving bed adsorptive separation processes, which are generally operated continuously at substantially constant pressures and temperatures that insure liquid phase, the desorbent material must be judiciously selected to satisfy many criteria. First, the desorbent material should displace an extract component from the adsorbent with reasonable mass flow rates.

Secondly, desorbent materials must be compatible with the particular adsorbent and the particular feed mixture. More specifically, they must not reduce or destroy the capacity of the adsorbent or selectivity of the adsorbent for an extract component with respect to a raffinate component. Additionally, desorbent materials should not chemically react with or cause a chemical reaction of either an extract component or a raffinate component.

Thirdly, desorbent materials should consist of a single solvent, or a binary mixture of solvents and complex solvent mixtures should be avoided, if possible.

Finally, desorbent materials should be readily available and reasonable in cost. The desorbent material of the mobile phase will have to be selected in each instance based upon the above criteria and its performance with the stationary phase.

As discussed above, columns with variable-lengths chromatographic zones are also feasible to be used in the present invention. Variable-lengths chromatographic zones are achievable if the shifting of different injection and draw-off points or a column, or column section, is carried out at different times instead of simultaneously. If that is the case, it should be noted that at the end of a cycle the system has regained its initial position.

It is advantageous to use a liquid as an eluent, but it is also possible to operate with a subcritical fluid.

The range of pressures in which the separations of products are carried out can be between 0.1 and 50 MPa and preferably between 0.5 and 30 MPa. The temperature in the columns is generally between 0°C. and 100°C.

## CHIRAL STATIONARY PHASE (CSP)





Prerequisites for scaling up a chromatographic analytical chiral separation into an SMB system is that the CSP is available in large amounts, with reproducible batch-to-batch properties and at a relatively low cost with respect to the value of the enantiomers to be separated. If this is fulfilled then the economical feasibility of the SMB process will be dictated by the key properties of the CSP namely selectivity, loading capacity and efficiency. These parameters later have an impact on the size of the unit and the achievable specific productivity of the process per unit mass of stationary phase. Other important issues are chemical stability, compatible mobile phases, and solubility of the enantiomers. All these characteristics have to be properly taken into account when selecting the CSP for an SMB system.






The CSPs most commonly used in enantioselective chromatography and SMB applications can be grouped as follows (see table 1 for some examples of chemical structure, commercial name and supplier).

- i. cellulose derivatives (e.g. esters or carbamates, preferably deposited on silica);
- ii. tartrate phases;
- iii.  $\pi$ -acidic and  $\pi$ -basic CSPs (Pirkle phases);
- iv. amylose derivatives (e.g. esters or carbamates, preferably deposited on silica)
- v. polyacrylamide phases.
- vi. others

**Table 1**

Structure and properties of commercial chiral stationary phases

Structure of CSP	chiral selector	trade name
 $R = \text{CH}_3$	microcrystalline cellulose- triacetate	MCTA or CTA-I
$R = $ 	cellulose tris(phenyl- carbamate)	Chiracel OJ
$R = $ 	cellulose tris(3,5- dimethylphenyl- carbamate)	Chiracel OD
$R = $ 	cellulose tribenzoate	Chiracel OB

Structure of CSP	chiral selector	trade name
	amylose tris(3,5-dimethylphenylcarbamate)	Chiralpak AD
	amylose tris[(S)-methylbenzylcarbamate]	Chiralpak AS-V
	O,O'-bis(4-tert-butyl-benzoyl)-N,N'-diallyl-L-tartardiamide	Kromasil CHI-TBB
	O,O'-bis(dimethylbenzoyl)-N,N'-diallyl-L-tartardiamide	Kromasil-CHI-DMB
	3,5-dinitrobenzoyl-phenylglycine (either ionic or covalent bonding)	DNBPG

Special care should be given to the following regarding stationary / mobile phase system used in SMB: a) retention time; b) enantioselectivity; c) loading capacity; d) productivity; e) eluent consumption; f) avoiding complex eluent mixtures or buffer additives.

*Cellulose based CSPs*

Table 2 shows an extensive data set of polysaccharide based stationary phases screened for chiral resolution of omeprazole using 10  $\mu\text{m}$  and 20  $\mu\text{m}$  stationary phases. 20  $\mu\text{m}$  stationary phases on silica particles is considered as the material of choice for scaling-up enantioselective preparative scale chromatographic separations since they combine low back pressure and sufficient resolution at high flow rates. It can be observed that most cellulosic stationary phases show relatively high  $k'$  values for the two enantiomers of omeprazole and some even show no chiral recognition ability. Long retention times lead in general to high cycle times and high eluent consumption. Surprisingly the cellulose based CSPs were found not to be the material of choice for scaling-up due to problem with scale-up and long retention times.

*Tartrate CSPs*

Table 5 shows an extensive data set of Tartrate CSPs screened for chiral resolution of omeprazole. Kromasil-CHI TBB, 16  $\mu\text{m}$  appears to be the most promising CSP and additional data for this CSP is shown in Table 6. Surprisingly the tartrate CSPs were found not to be the material of choice for scaling-up due to complex and expensive solvent mixtures as the desorbent material. The peak shapes of these systems were further not satisfying.

 *$\pi$ -Acidic and  $\pi$ -basic CSPs*

Table 7 shows data set of  $\pi$ -acidic and  $\pi$ -basic CSPs screened for chiral resolution of omeprazole. Surprisingly the  $\pi$ -acidic and  $\pi$ -basic CSPs were found not to be the material of choice for scaling-up due to complex and expensive solvent mixtures as the desorbent material and not sufficient loading capacity.

*Amylose based CSPs*

The tris(3,5-dimethylphenyl carbamate) derivative of amylose has been commercialized under the name Chiralpak AD, the tris[(S)-methylbenzylcarbamate] has been named Chiralpak AS. The latter derivative, as well as providing polar, polarizable sites, also

contributes another chiral center. The (S)-configured methyl group is also available as well the (R,S) and (R)-derivative. Table 3 shows an extensive data set using 20  $\mu\text{m}$  stationary Chiralpak AD. It should be noted that the results obtained for 10  $\mu\text{m}$  particle size stationary phase could not be reproduced with Chiralpak AD 20  $\mu\text{m}$  particle size material. Table 4 shows an extensive data set using 20  $\mu\text{m}$  stationary Chiralpak AS.

It was surprisingly found that the order in which the two enantiomers of omeprazole eluted reversed when going from 10  $\mu\text{m}$  particle size to 20  $\mu\text{m}$  particle size Chiralpak AS and EtOH/IPA 30/70 as the desorbent material. Using these conditions S-(-)-omeprazole is the more retained component and will elute in the extract, while R-(+)-omeprazole is the less retained component and will elute in the raffinate.

The enantiomeric excess (e.e.) in the raffinate and/or extract is usually above 90%, preferably above 95% or even more preferably above 98%. However since it is possible to improve the e.e. by a subsequent crystallization step, an e.e. of 60% in the raffinate and/or extract is sufficient to be able to prepare the compounds of the present invention. It is also possible to improve the e.e. by converting a compound of the present invention into a base addition salt thereof and crystallize the salt.

In one embodiment of the present invention the enantiomeric excess (e.e.) in the raffinate and/or extract is 60% and above, preferably above 70% or even more preferably above 80%. The e.e. is thereafter improved by a subsequent crystallisation step, optionally with a pre-conversion of the compound into a base addition salt.

The racemic mixture, *i.e.* a mixture containing equal amounts of the two enantiomers, is the most easily accessible mixture using traditional chemical synthesis. However use of enantioselective chemical synthesis and enzymatic synthesis may give other ratios of the two enantiomers. Both the racemic mixture and a mixture with any other ratio of the two enantiomers than a 50:50 ratio are suitable for the present invention. It is preferred to use the racemic mixture for practical reasons.

The process of the present invention is preferably used to isolate one of the enantiomers of either omeprazole, pantoprazole, lansoprazole, or rabeprazole. The other enantiomer might be discarded but is preferably taken through a racemisation procedure that generates a mixture containing both enantiomers with thereafter can be purified according to the present invention. Such a procedure is also within the scope of the present invention.

#### *Stability of omeprazole under chromatographic conditions*

It has previously been reported that alcoholic solution of omeprazole is not stable in room temperature and in daylight. There is thus a risk that one or several decomposition products might co-elute with one of the enantiomers. However, the addition of 0.1 % diethylamine, or any other similar organic amine, stabilizes a solution of omeprazole in methanol to a sufficient degree. We have now surprisingly found that omeprazole can be resolved into its two enantiomers using means for SMB and ethanol as the mobile phase.

#### *Simulation of SMB operating parameters*

To design and optimize a SMB separation, NOVASEP (Nancy, France) has developed a procedure based on the theory of multicomponent chromatography. This procedure includes mainly two steps:

1. Measuring the characteristics of the stationary phase. These data can include: competitive adsorption isotherms, Van-Deemter curve which gives HETP (the height equivalent to a theoretical plate) vs. the mobile phase velocity, the relationship between pressure drop and the mobile phase velocity.
2. The data measured in the previous steps are processed by NOVASEP's simulation software "softSMB", or any other suitable software such as LicoHELP, which will estimate the operating conditions and SMB parameters.

SoftSMB can be used to predict operating conditions and SMB parameters of the present invention. Predicted productivity and eluent consumption is shown in Figures 5 and 6.

The composition of the eluent of the present invention can be either isocratic, or a composition gradient. It is also recommended to add small amounts of an organic amine to stabilize the compounds of the present invention.

#### EXAMPLES

The following common abbreviations are used.

AA	acetic acid	IPA	isopropyl alcohol
ACN	acetonitrile	MeCl	dichloromethane
DEA	diethylamine	MeOH	methanol
EtOAc	ethyl acetate	MTBE	methyl tert. butyl ether
EtOH	etanol	n-Hex	n-hexane
IH	isohexane	TEA	triethylamine

#### *Example 1*

Stationary and mobile phases were screened for separation of Omeprazole into its enantiomers. Result is given below in Table 2.

**Table 2**

Systematic screening of stationary (cellulose based) and mobile phases for the separation of omeprazole into its enantiomers.



<b>Column: Chiralpak AD</b>							
<b>Mobile phase</b>	<b>Solute in</b>	<b>k<sub>1</sub>'</b>	<b>k<sub>2</sub>'</b>	<b><math>\alpha</math></b>	<b>R<sub>s</sub></b>	<b>Plates 1</b>	<b>Plates 2</b>
IH/IPA 90/10	IPA	7,40	8,98	1,21	-	268	
IH/IPA 70/30	IPA	1,37	1,71	1,25	-	361	
Ethanol	IPA	1,34	1,93	1,44	1,57	803	772
EtOH/IH 80/20	IPA	1,11	1,63	1,46	1,68	951	972
EtOH/IH 80/20+0.2TEA	IPA	1,60	1,99	1,24	-	-	-
Methanol	IPA	1,24	1,24	1,00	-	-	-
Acetonitrile	IPA	4,97	4,97	1,00	-	230	
<b>Column: Chiralpak AS</b>							
<b>Mobile phase</b>	<b>Solute in</b>	<b>k<sub>1</sub>'</b>	<b>k<sub>2</sub>'</b>	<b><math>\alpha</math></b>	<b>R<sub>s</sub></b>	<b>Plates 1</b>	<b>Plates 2</b>
IH/IPA 90/10	IPA	15,13			-	-	-
IH/IPA 70/30	IPA	2,90	5,80	2,00	2,55	670	262
Ethanol	IPA	0,54	0,78	1,43	1	933	696
IH/EtOH 70/30	IPA	1,92	2,97	1,55	3,02	1947	1332
IH/EtOH 65/35	IPA	1,61	2,51	1,56	2,72	1760	1181
IH/EtOH 65/35 + 0.2TEA	IPA	1,11	1,51	1,68	2,46	2124	682
Methanol	IPA	0,49	0,49	1,00	-	560	
Acetonitrile	IPA	0,93	1,22	1,32	1,3	1264	1387

<b>Column: Chiralcel OA</b>							
<b>Mobile phase</b>	<b>Solute in</b>	<b>k'<sub>1</sub></b>	<b>k'<sub>2</sub></b>	<b>α</b>	<b>R<sub>s</sub></b>	<b>Plates 1</b>	<b>Plates 2</b>
IH/IPA 90/10	IPA	6,92	7,99	1,15	-	-	-
IH/IPA 80/20	IPA	2,59	2,95	1,14	-	-	-
Ethanol	IPA	0,20	0,20	1,00	-	1790	
<b>Column: Chiralcel OB</b>							
<b>Mobile phase</b>	<b>Solute in</b>	<b>k'<sub>1</sub></b>	<b>k'<sub>2</sub></b>	<b>α</b>	<b>R<sub>s</sub></b>	<b>Plates 1</b>	<b>Plates 2</b>
IH/IPA 90/10	IPA	5,17	5,17	1,00	-	22	
IH/IPA 80/20	IPA	1,83	1,83	1,00	-	27	
Ethanol	IPA	0,17	0,17	1,00	-	608	
<b>Column: Chiralcel OD</b>							
<b>Mobile phase</b>	<b>Solute in</b>	<b>k'<sub>1</sub></b>	<b>k'<sub>2</sub></b>	<b>α</b>	<b>R<sub>s</sub></b>	<b>Plates 1</b>	<b>Plates 2</b>
IH/IPA 90/10	IPA	7,57	9,93	1,31	1,81	1012	1110
IH/IPA 80/20	IPA	2,83	3,69	1,30	1,7	1072	1142
IH/IPA 70/30	IPA	1,54	2,34	1,33	1,49	1054	1107
Ethanol	IPA	0,45	0,45	1,00	-	570	
Methanol	IPA	0,52	0,52	1,00	-	1023	
Acetonitrile	IPA	1,56	1,56	1,00	-	523	
IH/EtOH 70/30	IPA	1,00	1,27	1,27	1,24	1470	1446

<b>Column: Chiralcel OG</b>							
<b>Mobile phase</b>	<b>Solute in</b>	<b>k'1</b>	<b>k'2</b>	<b><math>\alpha</math></b>	<b>R<sub>s</sub></b>	<b>Plates 1</b>	<b>Plates 2</b>
IH/IPA 90/10	IPA	t <sub>r</sub> >60'			-	-	-
IH/IPA 80/20	IPA	7,61	9,60	1,26	1,58	831	1024
Methanol	IPA	0,49	0,59	1,20	0,82	2870	2336
<b>Column: Chiralcel OJ</b>							
<b>Mobile phase</b>	<b>Solute in</b>	<b>k'1</b>	<b>k'2</b>	<b><math>\alpha</math></b>	<b>R<sub>s</sub></b>	<b>Plates 1</b>	<b>Plates 2</b>
IH/IPA 90/10	IPA	4,80	7,05	1,47	2,55	888	1050
IH/IPA 80/20	IPA	1,73	2,33	1,35	1,49	928	888
IH/IPA 70/30	IPA	0,93	1,19	1,28	0,93	939	776
Ethanol	IPA	0,16	0,16	1,00	-	-	-
Methanol	IPA	0,15	0,15	1,00	-	-	-
EtOH/IH 10/90	IPA	4,00	4,83	1,21	0,75	766	251

*Example 2*

Chiralpak AS; 20  $\mu$ m particle size, is optimized for SMB. Results are given in Table 4.

**Table 4**

Chiralpak AS; 20  $\mu$ m particle size

mobile phase	dissolved in	R <sub>t1</sub> [min]	R <sub>t2</sub> [min]	$\alpha$
IH/EtOH 30/70	IPA	8.296	13.670	1.81
IH/EtOH 35/65	IPA	7.423	11.916	1.78

mobile phase	dissolved in	R <sub>1</sub> [min]	R <sub>2</sub> [min]	$\alpha$
IH/EtOH/DEA 30/70/0.2	IPA	7.362	11.685	1.75
ACN	IPA	5.731	7.532	1.44
EtOH	IPA	4.369	5.856	1.54
EtOH/IPA 30/70	IPA	5.487	8.902	1.92
EtOH/IPA 35/65	IPA	5.330	8.463	1.85

column: Chiralpak AS; 120 Å, d<sub>p</sub> = 20 µm, 250 mm x 4.6 mm, T = 25 °C, detection @ 334 nm, injected volume: 20 µL.

The similarities and differences of the solvent systems described in Table 4 have been analyzed in regard to productivity and solvent consumption in detail (cf. Example 8).

### Example 3

Additional stationary and mobile phases are screened for the separation of omeprazole into its enantiomers. Results are given in Table 5.

**Table 5**

Systematic screening of stationary (tartrate based) and mobile phases for the enantiomer separation of Omeprazole

Column: Kromasil-CHI-DMB							
Mobile phase	Solute in	k' <sub>1</sub>	k' <sub>2</sub>	$\alpha$	R <sub>s</sub>	Plates 1	Plates 2
IH/IPA 90/10	IPA	4,23	4,78	1,13	1,05	1952	1603
IH/EtOAc 50/50	EtOAc	4,28	5,61	1,31	2,46	1950	1918
IH/Dioxan 70/30	EtOAc	3,16	3,75	1,19	1,7	2678	2479
IH/MeCl 50/50	EtOAc	t <sub>r</sub> > 60'			-	-	-

IH/MTBE 70/30	EtOAc	$t_r > 60'$			-	-	-
IH/EtOAc/IPA 80/15/5	EtOAc	4,47	5,41	1,21	1,97	2628	2373
IH/EtOAc/IPA 60/35/5	EtOAc	2,57	3,13	1,22	1,92	2985	2727
IH/MTBE/IPA 50/35/15	EtOAc	1,79	2,11	1,18	1,21	2133	1752
IH/MTBE/IPA 50/40/10	EtOAc	3,06	3,77	1,23	1,74	1996	1777
IH/MeCl/IPA 60/30/10	EtOAc	0,59	0,59	1,00	-	-	-
Column: Kromasil-CHI-TBB							
Mobile phase	Solute in	$k'_1$	$k'_2$	$\alpha$	$R_s$	Plates 1	Plates 2
IH/IPA 90/10	IPA	3,93	5,32	1,35	2,71	1976	1851
EtOH	IPA	-	-	-	-	-	-
IH/Dioxan 70/30	EtOAc	3,24	4,67	1,44	2,91	1454	1913
IH/MeCl 50/50	EtOAc	7,65	9,06	1,18	-	-	-
IH/MeCl/IPA 60/30/10	EtOAc	0,25	0,25	1,00	-	-	-
IH/MeCl/IPA 80/15/5	EtOAc	2,49	3,24	1,30	1,70	1098	1380
IH/MeCl/IPA 70/25/5	EtOAc	1,20	1,52	1,26	1,37	1531	1918
IH/MTBE 70/30	EtOAc	-	-	-	-	-	-
IH/MTBE/IPA 50/35/15	EtOAc	1,72	2,48	1,44	2,51	1667	1604
IH/MTBE/IPA 50/40/10	EtOAc	3,02	4,54	1,50	3,04	1488	1430
IH/MTBE/IPA 50/40/10 +0.1%AA	EtOAc	3,39	4,99	1,47	3,51	2138	1979
IH/MTBE/IPA 50/40/10 +0.2%TEA	EtOAc	3,40	5,05	1,48	3,55	2111	1936
IH/MTBE/IPA 50/40/10+0.15%AA	EtOAc	3,19	4,67	1,46	3,48	2248	2069
IH/MTBE/IPA 45/45/10+0.1TEA	EtOAc	3,68	5,52	1,50	2,32	718	842
IH/EtOAc 70/30	EtOAc	-	-	-	-	-	-
IH/EtOAc 60/40	EtOAc	8,36	13,10	1,57	2,95	572	1143
IH/EtOAc 50/50	EtOAc	3,50	5,35	1,53	2,62	730	1157
IH/EtOAc/IPA 80/15/5	EtOAc	4,44	6,41	1,44	2,91	1381	1474
IH/EtOAc/IPA 75/20/5	EtOAc	3,72	5,11	1,37	-	-	-

IH/EtOAc/IPA 75/20/5	IPA	3,17	4,30	1,36	2,97	2302	2606
IH/EtOAc/IPA 75/20/5	IPA+TE A	3,37	4,54	1,35	2,35	1244	1921
IH/EtOAc/IPA 75/20/5+0.05AA,0.1TEA	IPA+TE A	3,36	4,63	1,38	3,70	3369	3364
IH/EtOAc/IPA 75/20/5+0.05AA,0.1TEA	EtOAc	4,20	5,87	1,40	4,39	4049	3931
IH/EtOAc/IPA 60/35/5	EtOAc	2,67	3,84	1,44	2,80	1553	1714
IH/EtOAc/IPA 60/35/5+0.1TEA	EtOAc	2,66	3,85	1,45	3,02	1821	1867

*Example 4*

Kromasil-CHI TBB, 16  $\mu\text{m}$  particle size, is evaluated as a potential CSP. The results are given in table 6.

**Table 6**

Kromasil-CHI TBB, 16  $\mu\text{m}$  particle size

mobile phase	dissolved in	$R_{t1}$ [min]	$R_{t2}$ [min]	$\alpha$
Ethanol	MeOH	3.428	-	1.00
IH/IPA 90/10	MeOH	12.584	15.857	1.29
IH/EtOH 90/10	MeOH	9.385	10.707	1.17

*Example 5*

(S)- $\alpha$ -Burke 2, 10  $\mu\text{m}$  particle size, is screened as a potential CSP. The result is given in Table 7.

**Table 7**  
(S)- $\alpha$ -Burke 2, 10  $\mu\text{m}$  particle size

mobile phase	dissolved in	R <sub>11</sub> [min]	R <sub>12</sub> [min]	$\alpha^*$
CH <sub>2</sub> Cl <sub>2</sub> /MeOH 95/5	MeOH	5.061	5.709	1.19
Methanol	MeOH	3.873	4.172	1.13

*Example 6*

Chiralpak AD; 20  $\mu\text{m}$  particle size, is optimized for SMB. Results are given in Table 3.

**Table 3**  
Chiralpak AD; 20  $\mu\text{m}$  particle size

mobile phase	dissolved in	R <sub>11</sub> [min]	R <sub>12</sub> [min]	$\alpha$
n-Hex/EtOH/ACN/DEA 53/31/16/0.1	MeOH	3.733	4.274	1.26
n-Hex/EtOH/ACN/DEA 69.7/20/10.3/0.1	MeOH	4.119	4.999	1.35
n-Hex/EtOH/ACN/DEA 79.8/3113.3/6.9/0.1	MeOH	4.864	6.641	1.55
n-Hex/EtOH/ACN/DEA 88.6/7.5/3.9/0.1	MeOH	7.386	12.749	1.93
Ethanol	MeOH	4.632	-	1.00
EtOH/TH 20/80	MeOH	4.402	-	1.00

*Example 7*

Simulation of SMB parameters using NOVASEP's simulation software softSMB.

The competitive adsorption isotherms have been determined using the procedures developed by NOVASEP; it was found that the experimental data fit well into the modified Langmuir competitive isotherm model. The model can be written as:

$$n_i = \lambda \cdot c_i + \frac{\bar{N}_i \cdot K_i \cdot c_i}{1 + \sum_{j=1}^2 K_j \cdot c_j}$$

In this equation  $n_i$  and  $c_i$  are the adsorbed and the fluid phase concentration, respectively;  $\lambda$  is a dimensionless constant;  $K_i$  is the equilibrium constant of the  $i$ -th component, which accounts for the overload effects; the upper limit of  $N_i$  is given by the saturation capacity and measures the amount of sample which can be loaded onto the column. The isotherm data for Chiralpak AS and various eluent compositions are summarized in the following table.

**Table 8**

Derived isotherms for various mobile phase combinations


<i>Experiment</i>	mobile phase	$\lambda$	$N_1 K_1$	$N_2 K_2$	$\bar{N}_i$
A	IH/EtOH 30/70	1.0	0.8612	3.016	28
B	IH/EtOH 35/65	1.5	0.8110	2.613	24
C	IH/EtOH/DEA 30/70/0.2	1.6	0.686	2.420	28
D	ACN	1.1	0.532	1.254	34
E	EtOH	0.5	0.585	1.182	44
F	EtOH/IPA 30/70	1.3	0.234	1.664	38
G	EtOH/IPA 35/65	1.2	0.271	1.528	30

column: Chiralpak AS; 120 Å,  $d_p = 20 \mu\text{m}$ , 250 mm x 4.6 mm,  $T = 25^\circ\text{C}$ , detection @ 334 nm.

**Example 8**

A comparison involving the daily productivity for a given SMB system with eight columns (10.1 cm x 4.8 cm ID; configuration 2-2-2-2) and the eluent consumption per day shows the following characteristics (cf. Figure 5):






**Figure 5:** comparison of various eluent systems (see Example 3) for Chiralpak AS, daily productivities normalized for 1 kg of chiral stationary phase.

*Example 9*

The eluent consumption was predicted. Figure 6 shows the result.



**Figure 6:** comparison of various eluent systems (see Table 8) for Chiralpak AS, daily eluent use for a 2-2-2-2 SMB system with identical columns (101 mm x 48 mm).

*Example 10*

The modeling/simulation results were confirmed by comparing experimental peak retention times and calculated retention times obtained from overloaded injections. In all cases, the agreements are reasonably good, for a comparison see the following table:

**Table 9**

Validation of simulation results

experiment No	concentration omeprazole [g/L]	injected Vol. [ $\mu$ L]	Rt <sub>1</sub> [min] measured	Rt <sub>1</sub> [min] calculated	Rt <sub>2</sub> [min] measured	Rt <sub>2</sub> [min] calculated
1	analytical	10	5.49	5.31	8.90	8.90
2	24.48	10	5.43	5.25	8.81	8.63
3	24.48	20	5.41	5.44	8.72	8.53
4	24.48	50	5.36	5.44	8.47	8.33
5	24.48	100	5.30	5.44	8.20	8.14
6	24.48	200	5.19	5.44	7.86	7.92
7	24.48	250	5.19	5.44	7.75	7.84

column: Chiralpak AS, 120 Å,  $d_p = 20 \mu\text{m}$ , 250 mm x 4.6 mm, T = 25 °C, detection @ 334 nm, injected volumes: see table.

*Example 11*

A suitable SMB system is used with Chiralpak AS as the CSP and with the parameters indicated below in Table 11. Optical purity of the extract and raffinate are also indicated in Table 11.

**Table 11**

Operating parameters, productivity and purities

<b>Operating parameters</b>	<b>Feed concentration</b>
(solvent system EtOH/IPA 30/70)	27.0 g/L
Recycling flow (Zone 1) [mL/min]	273.0
Extract flow [mL/min]	108.10
Feed flow [mL/min]	45.00
Eluent flow [mL/min]	118.27
Raffinate flow [mL/min]	55.17
Purity extract [%]	99.79
Purity raffinate [%]	99.94
Productivity [g/day]	1740

*Example 12 and 13*

In Examples 12 and 13 the following general procedure was used. The columns (diameter of 25,4 mm) of the LICOSEP Lab Eex was packed using Chiral Pak AS 20  $\mu$ m (Daicel). To reach a bed length of about 11 cm, 30 g of chiral stationary phase per column were used. Either a 2-2-2-2 or a 3-3-3-3 configuration was used, the mobile phase was pure ethanol and the feed concentration was fixed to 10 g omeprazole / liter.

Example #	Number of columns	Q feed (mL/min)	Q elu (mL/min)	Q ext (mL/min)	Q raf (mL/min)	Q rec (mL/min)	Switching Period (min)	Zone flow rates and purities
12	12	5,3	11,8	10,6	6,5	39,8	2.10	Zone I: 2,39 L/h Zone II: 1,75 L/h Zone III: 2,07 L/h Zone IV: 1,68 L/h Extract purity: 98.2%e.e. Raffinate purity: 99.6%e.e.
13	8	7,5	18,7	15,4	10,8	62,0	1.40	Zone I: 3,72 L/h Zone II: 2,82 L/h Zone III: 3,25 L/h Zone IV: 2,60 L/h Extract purity: 98,0%e.e. Raffinate purity: 99,1%e.e.

Using the conditions of Examples 12 and 13, above 98%e.e. and with the same bed length, the productivity would be 7,71 g/h for an SMB 8x50 and 133,9 g/h (1071 kg/year) for an SMB 8x200 for each enantiomer. This corresponds to a specific productivity of 438 g

mixture of the enantiomers / kg CSP /24 h. Thus, according to one embodiment of the present invention the specific productivity of for the production of enantiomerically pure or optically enriched enantiomer of omeprazole is above 400 g mixture of the enantiomers / kg CSP /24 h, preferably 300 to 500 g, more preferably about 400 to 500 g and even more preferably about 440 g mixture of the enantiomers / kg CSP /24 h.

## CLAIMS

1. A process for the preparation of an enantiomerically pure or optically enriched enantiomer of either omeprazole, pantoprazole, lansoprazole, or rabeprazole from a mixture of the enantiomers using means for simulated moving bed chromatography.
2. A process according to claim 1, characterized in that the mixture consists of the enantiomers of omeprazole.
3. A process according to claim 2, characterized in using amylose tris(S)-methylbenzylcarbamate as the CSP.
4. A process according to claim 4, characterized in using 20  $\mu\text{m}$  particle size of the CSP.
5. A process according to claim 2, characterized in using ethanol as the mobile phase system
6. A process according to claim 2, characterized in that S-(-)-omeprazole is eluting in the extract.
7. A process according to claim 2, characterized in that the enantiomeric excess in the extract and/or the raffinate is 98% or above.
8. A process for the preparation of an enantiomerically pure or optically enriched enantiomer of omeprazole from a mixture of the enantiomers using means for simulated moving bed chromatography and amylose tris(S)-methylbenzylcarbamate in 20  $\mu\text{m}$  particle size as the CSP and ethanol as the mobile phase system to resolve more than 400 g mixture of the enantiomers / kg CSP / 24 h with S-(-)-omeprazole eluting in the extract.

9. A process according to claim 9, characterized in that the enantiomeric excess is 95% or above.
10. A process according to claim 9, characterized in that the enantiomeric excess is 98% or above.

## INTERNATIONAL SEARCH REPORT

International application No.

PCT/SE 02/02356

## A. CLASSIFICATION OF SUBJECT MATTER

IPC7: C07D 401/12, C07B 57/00 // C07M 7/00  
According to International Patent Classification (IPC) or to both national classification and IPC

## B. FIELDS SEARCHED

Minimum documentation searched (classification system followed by classification symbols)

IPC7: C07D, C07M, B01D, C07B

Documentation searched other than minimum documentation to the extent that such documents are included in the fields searched

SE,DK,FI,NO classes as above

Electronic data base consulted during the international search (name of data base and, where practicable, search terms used)

WPI DATA, EPO-INTERNAL, PAJ, CA.ABS.DATA, MEDLINE, BIOSIS

## C. DOCUMENTS CONSIDERED TO BE RELEVANT

Category*	Citation of document, with indication, where appropriate, of the relevant passages	Relevant to claim No.
Y	Journal of Chromatography A, Volume 906, 2001; Michael Schulte et al, "PREPARATIVE ENANTIOSEPARATION BY SUMULTATED MOVING BED CHROMATOGRAPHY", page 399 - page 416, see sections 3.2, 3.3, table 6 --	1-10
Y	TIBTECH, Volume 18, March 2000, Markus Juza et al, "SIMULATED MOVING-BED CHROMATOGRAPHY AND ITS APPLICATION TO CHIOTECHNOLOGY", see the whole document --	1-10
Y	WO 0071539 A1 (PHARM-ECO LABORATORIES INC.), 30 November 2000 (30.11.00), page 1, line 19 - page 2, line 17, claims 1-4, abstract --	1-10

☒ Further documents are listed in the continuation of Box C.☒ See patent family annex.

## \* Special categories of cited documents:

- "A" document defining the general state of the art which is not considered to be of particular relevance  
 "E" earlier application or patent but published on or after the international filing date  
 "L" document which may throw doubts on priority claim(s) or which is cited to establish the publication date of another citation or other special reason (as specified)  
 "O" document referring to an oral disclosure, use, exhibition or other means  
 "P" document published prior to the international filing date but later than the priority date claimed

"T" later document published after the international filing date or priority date and not in conflict with the application but cited to understand the principle or theory underlying the invention

"X" document of particular relevance: the claimed invention cannot be considered novel or cannot be considered to involve an inventive step when the document is taken alone

"Y" document of particular relevance: the claimed invention cannot be considered to involve an inventive step when the document is combined with one or more other such documents, such combination being obvious to a person skilled in the art

"&" document member of the same patent family

Date of the actual completion of the international search

20 February 2003

Date of mailing of the international search report

24-02-2003

Name and mailing address of the ISA/  
 Swedish Patent Office  
 Box 5055, S-102 42 STOCKHOLM  
 Facsimile No. +46 8 666 02 86

Authorized officer

Lars Wallentin/MP  
 Telephone No. +46 8 782 25 00



## INTERNATIONAL SEARCH REPORT

International application No.

PCT/SE 02/02356

## C (Continuation). DOCUMENTS CONSIDERED TO BE RELEVANT

Category*	Citation of document, with indication, where appropriate, of the relevant passages	Relevant to claim No.
Y	Journal of Chromatography A, Volume 660, No 1-2, February 1994, Karin Balmér et al, "STEREOSELECTIVE EFFECTS IN THE SEPARATION OF ENANTIOMERS OF OMEPRAZOLE AND OTHER SUBSTITUTED BENZIMIDAZOLES ON DIFFERENT CHIRAL STATIONARY-PHASES", page 269 - page 273, abstract --	1-10
Y	National Library of Medicine (NLM), file Medline, Medline accession no. 8710755, Katsuki H et al; "Determination of R (+)- and S (-) - lansoprazole using chiral stationary-phase liquid chromatography and their enantioselective pharmacokinetics in humans"; & Pharmaceutical research, volume 13, no. 4, April 1996, page 611-615, abstract -- -----	1-10

**International application No.**  
**PCT/SE 02/02356**

Patent document cited in search report	Publication date	Patent family member(s)	Publication date
WO 0071539 A1	30/11/00	AU 5172000 A EP 1180104 A	12/12/00 20/02/02